

**Confirmatory Survey of Building 4020
Concrete Blocks
Santa Susana Field Laboratory
Boeing - Rocketdyne
Ventura County, California**

Prepared By
Roger K. Lupo, Health Physicist

Radiological Assessment Unit
Radiologic Health Branch

Preparation Date: 9-27-99

Reviewed by: Steve Hsu Date: 9/27/99

Introduction:

The concrete blocks and materials were generated from the sectioning of the walls and floors of the Rockwell International Hot Laboratory (RIHL) during demolition of the building. At the time of demolition, these blocks (85 decontaminated structural concrete sections s/n 568A, 764 – 809A, 809B - 845) were found to have surface radioactive contamination and they were subsequently decontaminated by Boeing-Rocketdyne. The purpose of this survey is to determine if the blocks may be released for unrestricted use as defined in DECON – 1 (Guidelines for Decontamination of Facilities and Equipment Prior to Release for Unrestricted Use).

Reference Document:

1. Letter 99RC-2696, with enclosures, from James Barnes to Roger Lupo, "Disposal of Rockwell International Hot Lab (RIHL) Wall Section Blocks", July 2, 1999.

Survey Personnel:

Roger Lupo, Lisa Brown and John Rexroth of the Radiological Health Branch performed a confirmatory survey on July 29, 1999.

Survey Instruments:

| Manufacture & Model | S/N | Probe/detector | S/N | Calibration due date |
|---------------------|--------|---|----------|----------------------|
| Ludlum Micro R m-19 | 80435 | Internal NaI 1x1 scint. | NA | 5/1/1999 |
| Ludlum Micro R m-19 | 42969 | Internal NaI 1x1 scint. | NA | 7/1/2000 |
| Ludlum model 3 | 134076 | 44 – 2 NaI 1x1 scint. | PR137133 | 12/1/1999 |
| Ludlum model 18 | 105775 | 44 – 9 G-M pancake | PR110029 | 11/8/1999 |
| Ludlum model 2224 | 149367 | 43 – 89 100 cm ² dual scint. | PR154122 | 9/26/1999 |

Survey Report:

The equipment listed in the above table were function checked and background measurements were taken. Background measurements are listed in Table 1. A general survey with a NaI detector sensitive to gamma photons of all the blocks and a GM pancake (beta/gamma) survey of a selected number of the blocks were performed by Radiologic Health Branch personal. The general gamma survey measurements ranged between 2500 cpm and 3500 cpm. The blocks selected at random for survey by G-M pancake had measurements ranging between 20 and 200 cpm. Direct measurements and swipe samples were taken from selected blocks. The swipe samples were sent to the Sanitation and Radiation Laboratory Branch (SRLB) in Berkeley. The survey results are listed in Table 2 and the SRLB analysis results of the swipe sample are listed in Table 3.

Table 1: Background Measurements

Measurements made at Building 4038

| Meter | Reading |
|--|----------------------------|
| Ludlum Micro R m-19 (Exposure rate) | 12 – 14 μ R/hr |
| Ludlum model 3 w/ 44 – 2 1x1 NaI (gamma) | 2.5K to 3K cpm |
| Ludlum model 18 w/ 44 – 9 GM (beta & gamma) | 60 to 110 cpm |
| Ludlum model 2224 w/ 43-89 (alpha and/or beta) | 2 cpm alpha / 622 cpm beta |

Table 2: Field Survey Data

Concrete Block Survey July 29, 1999 Building 4020 (hot cell) debris all measurements are gross count numbers.

| Item # | Swipe ID ¹ | Block Id | μ R/hr | gamma scan (cpm) | G-M scan (cpm) | contact measurements ¹ | | | |
|--------|-----------------------|----------|------------|------------------|----------------|-----------------------------------|-------------|------------|------------------|
| | | | | | | μ R/hr | alpha (cpm) | beta (cpm) | beta/gamma (cpm) |
| 1 | | 568A | 12 - 15 | 3k - 3.5k | * | | | | |
| 2 | | 764 | 12 - 15 | 3k - 3.5k | * | | | | |
| 3 | | 765 | 12 - 15 | 3k - 3.5k | * | | | | |
| 4 | 6 | 766 | 12 - 15 | 3k - 3.5k | 20 - 110 | 11 | 1 | 517 | 60 - 80 |
| 5 | | 767 | 12 - 15 | 3k - 3.5k | * | | | | |
| 6 | | 768 | 12 - 15 | 3k - 3.5k | 60 - 110 | | | | |
| 7 | | 769 | 12 - 15 | 3k - 3.5k | 80 - 160 | | | | |
| 8 | | 770 | 12 - 15 | 3k - 3.5k | * | | | | |
| 9 | | 771 | 12 - 15 | 3k - 3.5k | * | | | | |
| 10 | | 772 | 12 - 15 | 3k - 3.5k | * | | | | |
| 11 | | 773 | 12 - 15 | 3k - 3.5k | * | | | | |
| 12 | | 774 | 12 - 15 | 3k - 3.5k | * | | | | |
| 13 | | 775 | 12 - 15 | 3k - 3.5k | 60 - 110 | | | | |
| 14 | | 776 | 12 - 15 | 3k - 3.5k | 60 - 180 | | | | |
| 15 | | 777 | 12 - 15 | 3k - 3.5k | 60 - 180 | | | | |
| 16 | | 778 | 12 - 15 | 3k - 3.5k | 60 - 180 | | | | |
| 17 | | 779 | 12 - 15 | 3k - 3.5k | 60 - 180 | | | | |
| 18 | | 780 | 12 - 15 | 3k - 3.5k | * | | | | |
| 19 | | 781 | 12 - 15 | 3k - 3.5k | * | | | | |
| 20 | | 782 | 12 - 15 | 3k - 3.5k | 40 - 140 | | | | |
| 21 | 7 | 783 | 12 - 15 | 3k - 3.5k | * | 11 | 6 | 620 | 80 - 90 |
| 22 | | 784 | 12 - 15 | 3k - 3.5k | * | | | | |
| 23 | | 785 | 12 - 15 | 3k - 3.5k | * | | | | |
| 24 | | 786 | 12 - 15 | 3k - 3.5k | * | | | | |
| 25 | | 787 | 12 - 15 | 3k - 3.5k | * | | | | |
| 26 | | 788 | 12 - 15 | 3k - 3.5k | * | | | | |
| 27 | | 789 | 12 - 15 | 3k - 3.5k | * | | | | |

| Item # | Swipe ID ¹ | Block Id | μ R/hr | gamma scan (cpm) | G-M scan (cpm) | contact measurements ¹ | | | |
|--------|-----------------------|----------|------------|------------------|----------------|-----------------------------------|-------------|------------|------------------|
| | | | | | | μ R/hr | alpha (cpm) | beta (cpm) | beta/gamma (cpm) |
| 28 | | 790 | 12 – 15 | 3k – 3.5k | * | | | | |
| 29 | | 791 | 12 – 15 | 3k – 3.5k | * | | | | |
| 30 | | 792 | 12 – 15 | 3k – 3.5k | * | | | | |
| 31 | | 793 | 12 – 15 | 3k – 3.5k | 60 – 120 | | | | |
| 32 | | 794 | 12 – 15 | 3k – 3.5k | 60 – 140 | | | | |
| 33 | | 795 | 12 – 15 | 3k – 3.5k | * | | | | |
| 34 | | 796 | 12 – 15 | 3k – 3.5k | * | | | | |
| 35 | | 797 | 12 – 15 | 3k – 3.5k | * | | | | |
| 36 | | 798 | 12 – 15 | 3k – 3.5k | * | | | | |
| 37 | | 799 | 12 – 15 | 3k – 3.5k | 60 – 120 | | | | |
| 38 | | 800 | 12 – 15 | 3k – 3.5k | * | | | | |
| 39 | | 801 | 12 – 15 | 3k – 3.5k | * | | | | |
| 40 | 9 | 802 | 12 – 15 | 3k – 3.5k | 20 – 200 | 11.5 | 4 | 598 | 60 |
| 41 | | 803 | 12 – 15 | 3k – 3.5k | * | | | | |
| 42 | 5 | 804 | 12 – 15 | 3k – 3.5k | 60 – 120 | 7.5 | 5 | 343 | 40 – 50 |
| 43 | | 805 | 12 – 15 | 3k – 3.5k | 60 – 110 | | | | |
| 45 | 8 | 806 | 12 – 15 | 3k – 3.5k | * | 10 | 3 | 578 | 60 – 80 |
| 46 | | 807 | 12 – 15 | 3k – 3.5k | 40 – 150 | | | | |
| 47 | | 808 | 12 – 15 | 3k – 3.5k | * | | | | |
| 48 | 3 | 809A | 12 – 15 | 3k – 3.5k | 40 – 100 | 10 | 4 | 645 | 80 |
| 49 | | 809B | 12 – 15 | 3k – 3.5k | * | | | | |
| 50 | | 810 | 12 – 15 | 3k – 3.5k | 50 – 100 | | | | |
| 51 | 10 | 811 | 12 – 15 | 3k – 3.5k | * | 7 | 3 | 633 | 65 – 85 |
| 52 | | 812 | 12 – 15 | 3k – 3.5k | * | | | | |
| 53 | | 813 | 12 – 15 | 3k – 3.5k | 40 – 120 | | | | |
| 54 | | 814 | 12 – 15 | 3k – 3.5k | * | | | | |
| 55 | | 815 | 12 – 15 | 3k – 3.5k | * | | | | |
| 56 | | 816 | 12 – 15 | 3k – 3.5k | * | | | | |
| 57 | 4 | 817 | 12 – 15 | 3k – 3.5k | * | 11 | 3 | 891 | 70 – 90 |

| Item # | Swipe ID ¹ | Block Id | μ R/hr | gamma scan (cpm) | G-M scan (cpm) | contact measurements ¹ | | | |
|--------|-----------------------|----------|------------|------------------|----------------|-----------------------------------|-------------|------------|------------------|
| | | | | | | μ R/hr | alpha (cpm) | beta (cpm) | beta/gamma (cpm) |
| 58 | | 818 | 12 – 15 | 3k – 3.5k | 80 – 140 | | | | |
| 59 | | 819 | 12 – 15 | 3k – 3.5k | * | | | | |
| 60 | | 820 | 12 – 15 | 3k – 3.5k | * | | | | |
| 61 | | 821 | 12 – 15 | 3k – 3.5k | 80 – 100 | | | | |
| 62 | | 822 | 12 – 15 | 3k – 3.5k | * | | | | |
| 63 | | 823 | 12 – 15 | 3k – 3.5k | * | | | | |
| 64 | | 824 | 12 – 15 | 3k – 3.5k | 80 – 160 | | | | |
| 65 | | 825 | 12 – 15 | 3k – 3.5k | * | | | | |
| 66 | 2 | 826 | 12 – 15 | 3k – 3.5k | * | 12 | 0 | 611 | 80 – 90 |
| 67 | | 827 | 12 – 15 | 3k – 3.5k | * | | | | |
| 68 | | 828 | 12 – 15 | 3k – 3.5k | * | | | | |
| 69 | | 829 | 12 – 15 | 3k – 3.5k | * | | | | |
| 70 | | 830 | 12 – 15 | 3k – 3.5k | * | | | | |
| 71 | | 831 | 12 – 15 | 3k – 3.5k | 60 – 110 | | | | |
| 72 | | 832 | 12 – 15 | 3k – 3.5k | 60 – 120 | | | | |
| 73 | | 833 | 12 – 15 | 3k – 3.5k | * | | | | |
| 74 | | 834 | 12 – 15 | 3k – 3.5k | * | | | | |
| 75 | | 835 | 12 – 15 | 3k – 3.5k | * | | | | |
| 76 | | 836 | 12 – 15 | 3k – 3.5k | 40 – 100 | | | | |
| 77 | | 867 | 12 – 15 | 3k – 3.5k | 60 – 120 | | | | |
| 78 | | 838 | 12 – 15 | 3k – 3.5k | * | | | | |
| 79 | | 839 | 12 – 15 | 3k – 3.5k | * | | | | |
| 80 | 1 | 840 | 12 – 15 | 3k – 3.5k | * | 15 | 1 | 633 | 60 – 80 |
| 81 | | 841 | 12 – 15 | 3k – 3.5k | 40 – 180 | | | | |
| 82 | | 842 | 12 – 15 | 3k – 3.5k | * | | | | |
| 83 | | 843 | 12 – 15 | 3k – 3.5k | * | | | | |
| 84 | | 844 | 12 – 15 | 3k – 3.5k | * | | | | |
| 85 | | 845 | 12 – 15 | 3k – 3.5k | 60 – 110 | | | | |

1. Wipe samples were collected for approximately 10 % of the number of blocks for a confirmatory survey.

Table 3: Sanitation and Radiation Laboratory Results.

| Block ID | Wipe ID | Laboratory Analysis | Results \pm CE (pCi/100cm ²) | Results \pm CE (dpm/100cm ²) |
|-----------|---------|---------------------------|---|---|
| 840 | 1 | Gross alpha Gross Beta | N.D. 1.59 \pm 0.43 | N.D. 3.53 \pm 0.95 |
| 826 | 2 | Gross alpha Gross Beta | N.D. N.D. | N.D. N.D. |
| 809A | 3 | Gross alpha Gross Beta | N.D. 1.81 \pm 0.44 | N.D. 4.02 \pm 0.98 |
| 817 | 4 | Gross alpha Gross Beta | N.D. 2.98 \pm 0.49 | N.D. 6.62 \pm 1.09 |
| 804 | 5 | Gross alpha Gross Beta | N.D. N.D. | N.D. N.D. |
| 766 | 6 | Gross alpha Gross Beta | N.D. N.D. | N.D. N.D. |
| 783 | 7 | Gross alpha Gross Beta | N.D. 1.09 \pm 0.40 | N.D. 2.42 \pm 0.89 |
| 806 | 8 | Gross alpha Gross Beta | 0.397 \pm 0.247 1.77 \pm 0.44 | 0.88 \pm 0.55 3.93 \pm 0.98 |
| 802 | 9 | Gross alpha Gross Beta | N.D. 0.865 \pm 0.394 | N.D. 1.92 \pm 0.87 |
| 811 | 10 | Gross alpha Gross Beta | N.D. N.D. | N.D. N.D. |
| composite | 1 - 10 | Gamma Scan (Cs-137) | 3.97 \pm 1.44 (pCi/10 wipes) | 8.81 \pm 3.20 (pCi/10 wipes) |

CE \rightarrow counting error at the 95% confidence level.N.D. \rightarrow Not Detected**Summary:**

The survey results of the representative samples of concrete blocks were at background levels. The results of the contact measurements and the laboratory analysis of collected samples indicate activity levels below the acceptable surface contamination levels listed in DECON-1 (Guidelines for Decontamination of Facilities and Equipment Prior to Release for Unrestricted Use). I recommend the 85 decontaminated structural concrete sections be released for unrestricted use.

Prepared by: Reginald LupoDate: 9-27-99